

D OVERALL COMPOSITION

1. SYSTEM CONFIGURATION

1.2 Configuration for optional device

Note

- The combination except as mentioned in the following is prohibited.
- IC-306/307/413/601 are available with all combinations.
- The options can be connected each other. However, be sure to take note of the AC connection mode.
- When using the C7000P/C70hc, the installation of the image controller (IC-XXX) is required.

1.2.1 Coupling combination of the main body and the paper feed option

Coupling combination of the main body and the paper feed option				AC power to be connected to
1	MB-504		Main body	-
2	LU-202*1		Main body	-
3	PF-602*2		Main body	-
4	LU-202*1	MB-504	Main body	-

*1 HT-503 can be connected arbitrarily to LU-202.

*2 HT-504/505 can be connected arbitrarily to PF-602.

1.2.2 Coupling combination of the main body and the finisher option

Coupling combination of the main body and the finisher option							AC power to be connected to
1	Main body	RU-509*1	FD-503				External (PF-509/FD-503)
2	Main body	RU-509*1	FD-503		LS-505		External (RU-509/FD-503/LS-505)
3	Main body	RU-509*1	FD-503		SD-506		External (RU-509/FD-503/SD-506)
4	Main body	RU-509*1	FD-503		FS-521		External (PF-509/FD-503)
5	Main body	RU-509*1	FD-503		PB-503		External (RU-509/FD-503/PB-503)
6	Main body	RU-509*1	FD-503		LS-505	SD-506	External (RU-509/FD-503/LS-505/SD-506)
7	Main body	RU-509*1	FD-503		LS-505	FS-521	External (RU-509/FD-503/LS-505)
8	Main body	RU-509*1	FD-503		LS-505	PB-503	External (RU-509/FD-503/LS-505/PB-503)
9	Main body	RU-509*1	FD-503		SD-506	FS-521	External (RU-509/FD-503/SD-506)
10	Main body	RU-509*1	FD-503		SD-506	PB-503	External (RU-509/FD-503/SD-506/PB-503)
11	Main body	RU-509*1	FD-503	SD-506	PB-503	FS-521	External (RU-509/FD-503/SD-506/PB-503)
12	Main body	RU-509*1	FD-503		PB-503	FS-521	External (RU-509/FD-503/PB-503)
13	Main body	RU-509*1	FD-503		LS-505	LS-505	External (RU-509/FD-503/LS-505)
14	Main body	RU-509*1	LS-505				External (RU-509/LS-505)
15	Main body	RU-509*1	LS-505		SD-506		External (RU-509/LS-505/SD-506)
16	Main body	RU-509*1	LS-505		FS-521		External (RU-509/LS-505)
17	Main body	RU-509*1	LS-505		PB-503		External (RU-509/LS-505/PB-503)
18	Main body	RU-509*1	LS-505		SD-506	FS-521	External (RU-509/LS-505/SD-506)
19	Main body	RU-509*1	LS-505		SD-506	PB-503	External (RU-509/LS-505/SD-506/PB-503)
20	Main body	RU-509*1	LS-505		PB-503	FS-521	External (RU-509/LS-505/PB-503)
21	Main body	RU-509*1	LS-505		LS-505		External (RU-509/LS-505)
22	Main body	RU-509*1	LS-505	LS-505	SD-506		External (RU-509/LS-505/SD-506)
23	Main body	RU-509*1	LS-505	LS-505	FS-521		External (RU-509/LS-505)

24	Main body	RU-509*1	LS-505	LS-505	PB-503		External (RU-509/LS-505/ PB-503)
25	Main body	RU-509*1	SD-506				External (RU-509/SD-506)
26	Main body	RU-509*1	SD-506		FS-521		External (RU-509/SD-506)
27	Main body	RU-509*1	SD-506		PB-503		External (RU-509/SD-506/ PB-503)
28	Main body	RU-509*1	SD-506		PB-503	FS-521	External (RU-509/SD-506/ PB-503)
29	Main body	RU-509*1	FS-521				External (RU-509)
30	Main body	RU-509*1	PB-503				External (RU-509/PB-503)
31	Main body	RU-509*1	PB-503		FS-521		External (RU-509/PB-503)
32	Main body	RU-509*1	GP-501	RU-506		FS-521	External (RU-509/GP-501)
33	Main body	RU-509*1	GP-501	RU-506	FD-503	FS-521	External (RU-509/FD-503/ GP-501)
34	Main body	RU-509*1	GP-501	RU-506	LS-505	FS-521	External (RU-509/LS-505/ GP-501)
35	Main body	RU-509*1	GP-501	RU-506	SD-506	FS-521	External (RU-509/SD-506/ GP-501)
36	Main body	RU-509*1	GP-501	RU-506	PB-503	FS-521	External (RU-509/PB-503/ GP-501)
37	Main body	RU-509*1	GP-501	RU-506	LS-505	PB-503	External (RU-509/LS-505/ PB-503/GP-501)
38	Main body	OT-502					-
39	Main body	RU-509*1 *3	FS-531*2 *3				External (RU-509)
40	Main body	RU-509*1 *3	FS-612*2 *3				External (RU-509)

*1 HM-102 can be connected arbitrarily to RU-509.

*2 PK-512/513 and PI-502 can be connected arbitrarily to FS-531/612.

*3 It is selectable to connect FS-531/612 to the main body directly or via RU-509.