
16.5 Other image stabilization controls

16.5.1 Charge potential automatic adjustment

- Adjust the charge potential of Y, M, C, and K collectively from the Service Mode after cleaning the charging corona.
- The method is the same as V0 correction on the image stabilization batch correction control. (Refer to [O.16.3.5 V0 correction](#))

16.5.2 Pre-agitation when left unused

(1) Purpose

- To agitate the toner in the developing unit automatically when the idling status persists for more than a prescribed period of time.

(2) Operation condition

- The idling status persists for more than a prescribed period of time.
- When restarting the print after a specified time passed since the last printing ended.

(3) Contents of the control

- Performs the developer pre-agitation.
- The speed is 300mm/s.

DRAFT